

JetCam Firmware Update Guide



January 2019

International Distributor



Sky Blue Microsystems GmbH Geisenhausenerstr. 18 81379 Munich, Germany +49 89 780 2970, info@skyblue.de www.skyblue.de The JetCam Cameras supports firmware update via USB using a serial emulated terminal. To initiate a firmware update follow the next steps:

- Download the latest firmware from <u>KAYAs FTP server</u>.
 Please make sure to download the correct FW for the camera that you have, as installing an incorrect FW may cause the camera to malfunction.
- Connect a USB cable between the computer and the camera and acquire connection using Silabs drivers (drivers need to be downloaded manually if an automatic download isn't initiated).
- 3. Open serial emulated terminal (usage of Tera Term terminal is recommended) and set serial communication protocol as described in the table below:

Parameter	Value		
Baud rate	115200		
Start bits	1		
Stop bits	1		
Parity	None		
Flow Control	None		

For example in the Tera Term terminal, this should look as following (the port number might be different):

Tera Term: Serial port setup			×	
Port:	COM10	\sim	ОК	
Baud rate:	115200	~		
Data:	8 bit	\sim	Cancel	
Parity:	none	\sim		
Stop:	1 bit	\sim	<u>H</u> elp	
Flow control:	none	\sim		
Transmit delay 0 msec/ <u>c</u> har 0 msec/ <u>l</u> ine				

4. Choose the firmware update option by entering "firmware" followed by a carriage return and wait for the following message: "Now starting firmware update, please start file transfer using XMODEM:"



5. Under the "File" tab use the terminal "transfer" capability using the XMODEM protocol to initiate the firmware update. Choose "Send" and the firmware update file: *JetCam_XXX_YYY_ZZZ*.bin (where XXX is the model name and YYY_ZZZ is the version number)



6. If no firmware will be sent during 1 minute, or in case of an error, the firmware update will fail and return to the previous operation mode:

```
JETCAM:> firmware
Now starting firmware update, please start file transfer using XMODEM:
update has failed
```

7. The firmware update process will take about 10 minutes.



8. A successful update will result in an appropriate message:



9. To apply the new firmware, the camera should be power cycled by disconnecting the power supply from the camera and connecting it back after a few seconds.

International Distributor



Sky Blue Microsystems GmbH Geisenhausenerstr. 18 81379 Munich, Germany +49 89 780 2970, info@skyblue.de www.skyblue.de